

R S L

Refreshment Systems Ltd.

Cleaning Guide

Marco Bru 60



Contact us

www.refreshmentsystems.co.uk

For Service:
service@refreshmentsystems.co.uk
01274 750 008

For Ingredients:
ingredients@refreshmentsystems.co.uk
01226 720 482

This cleaning guide is for **advice only**

Please refer to the operative manual for complete safety information and instruction when considering any maintenance on the machine.

TROUBLESHOOTING

Fault	Probable Cause	Action
Brewing neon does not light, unit will not brew	The unit is not switched on	Check the unit is plugged in correctly and switched on
	Plug and lead are damaged	Call a qualified service technician
	Fuse in the plug has blown	Replace the plug fuse
	Power supply	Check power supply
	Internal wiring fault	Call a qualified service technician
	Float switch has failed	Call a qualified service technician
Brewing neon is lit but unit will not brew	Thermal switch is activated	Reset thermal switch(es) and descale the unit
	Element failure	Replace the boiler
Water coming from under the unit	The overflow is operating, the tank is being over-filled	Perform water only" brew to drain excess water
The coffee is too weak	Not enough ground coffee has been used	Increase the amount of coffee
	Coffee grind is too coarse	Reduce the coarseness of the grind
The coffee is too strong	Too much ground coffee has been used	Reduce the amount of coffee
	Coffee grind is too fine	Increase the coarseness of the grind
	Not enough water has been used	Increase the amount of water
The basket is overflowing.	Coffee grind is too fine	Increase the coarseness of the grind
	Too much ground coffee has been used	Reduce the amount of coffee
Insufficient water pressure	Water pipe not connected	Connect water pipe to the rear of the machine.











